

Quick Reference Guide

General Information	1
Periodic Maintenance	2
Fuel System	3
Cooling System	4
Engine Top End	5
Converter System	6
Recoil Starter	7
Engine Lubrication System	8
Engine Removal/Installation	9
Crankshaft/Transmission	10
Wheels/Tires	11
Final Drive	12
Brakes	13
Suspension	14
Steering	15
Frame	16
Electrical System	17
Appendix	18

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.